



SINGER®

ORIGINAL SINCE 1851.

With electronic-enabled features and an LCD screen, the SINGER® | C7225 Computerized Sewing Machine is great for beginners and advanced sewists alike. The 200 built-in stitches offer 417 stitch applications to give you the right stitch for any fabric, from lightweight sheer to multiple layers of denim. A full instruction manual is available online to view or download anytime.

FEATURES & BENEFITS

417 Stitch Applications

Wide range of sewing techniques for creativity and customization.

LCD Screen

Clearly displays your selected stitch, as well as, stitch settings for length and width.

Lettering Font

Personalize projects with custom words, phrases or monograms.

Thread Cutter

Trim both the top and bobbin threads with the touch of a button.

Touch Button Stitch Selection

Use the touch buttons under the LCD window to select your stitch, and also view your stitch's length and width settings.

8 Automatic 1-Step Buttonhole Styles

Create consistent buttonholes in a style to suit your needs.

StayBright™ LED Lights

Multiple lights on both sides of the needle provide clear view of the sewing area while eliminating shadows.

Needle Threader

Effortless threading of the needle for a faster start.

Extension Table Included

Provides a level sewing surface to sew larger projects.

Start/Stop Button

Allows you to sew without using the foot control.

Heavy Duty Metal Frame

Full interior metal frame provides long lasting durability.

C7225 Computerized Sewing Machine



INCLUDED ACCESSORIES

- All Purpose Foot
- Satin Stitch Foot
- Blind Hem Foot
- Zipper Foot
- Buttonhole Foot
- Button Sewing Foot
- Cording Foot
- Open Toe Foot
- Edge/Quilting Guide
- Spool Pin Felt
- Screwdriver
- Needle Plate Screwdriver
- Seam Ripper / Lint Brush
- Thread Spool Caps
- Auxiliary Spool Pin
- Bobbins
- Needles

Extension Table
Included



singer.com